




Assembly Instruction

Item No : 58903NS / 58904NS


Description: Nightstand

LILOLA
L I V I N G

TOOL REQUIRED



PARTS LIST




USEFUL HINTS BEFORE YOU START:


1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damp cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

HARDWARE LIST


- 1 BLACK LARGE
HIDDEN CAM - 16




- 2 SMALL HIDDEN
CAM - 2




- 3 CAM DOWEL - 8




- 4 CAM SCREW - 10




- 5 WOOD DOWEL - 16




- 6 PULL - 1




- 7 APPLIQUE CARD - 1



- 8 1-3/4" FLAT HEAD SCREW - 6




- 9 1-1/2" FLAT HEAD SCREW - 4




- 10 3/4" MACHINE SCREW - 2




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 8




Step 9




Step 10




Step 11




Step 12




Step 13




Step 14




Step 15




Step 16




Step 17



Step 18




Step 19



Step 20

Loosen screw #2 a 1/4 turn, the cam a 1/4 turn maximum in both the clockwise and counter-clockwise directions to make adjustments, and then tighten screw #2



The higher the screw in the oblong hole, the higher your drawer front will be. The lower the screw, the lower the drawer front.

