


ASSEMBLY INSTRUCTION

ITEM NO: 97036 97040



Necessary assmbly time: 60 minutes.

ΕN

Thank you for purchase on our products, please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you.


Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use .

- 1. During the assembly process, keep all parts away form babies or children.
- 2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
- 3. Use of tip-over restraints may only reduce, but not eliminate the risk oftip-over.
- 4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
- 5. Place the heaviest items on the lowest shelf.
- 6. Never allow children to climb or bang on drawers, doors or shelves.

Parts List



Hardware List









Not provided			
A	В	С	D
Cam bolt 37PCS	Cam lock 37PCS	Wood dowel 32PCS	Flat head screw 4PCS
E E	F	G	H
Flat head screw 6PCS	Bracket 12PCS	Flat head screw 12PCS	Hinge 8PCS
	J	K	L
Flat head screw 48PCS	handle 4PCS	Bolt 4PCS	Silicone sheet 4PCS
M	N	N1	N2
Shelf pin 8PCS	Heater 1PC	L-Brackets 2PCS	Screws 6PCS
LED light bars 2PCS	N4 Hook 2PCS	Prevent from toppling 2PCS	

Assembly Steps

